SECTION 11110

TUMBLE DRYER, 120 LB. (54.4 KG) CAPACITY

PART 1 GENERAL

1.01 SECTION INCLUDES:

A. Automatic laundry dryer for processing water-washed linen items

1.02 SYSTEM DESCRIPTION

- A. DESIGN REQUIREMENTS:
 - 1. Dry weight capacity: 120 lb. (54.4 kg)
 - 2. Cylinder volume: 36.1 cu ft (1022238 cu cm) minimum
 - 3. Construction: Heavy duty embossed steel with e-coat and baked enamel powder paint
 - 4. Input voltage: 208-240/60/3
 - 5. Heat source: Steam, 11.7 BHP, 405,000 BTU, 3/4 inch (19 mm) NPT
 - 6. Overall width: 46.38 inches (1178 mm) nominal
 - 7. Overall height: 83.5 inches (2121 mm) nominal
 - 8. Overall depth: 67.92 inches (1725 mm) nominal
 - 9. Exhaust size: 10 inch (254 mm)
 - 10. Control system: Microprocessor touchpad control
 - 11. Stainless steel door: High grade stainless steel door with 7/8 inch (22 mm) rubber gasket and heavy duty hinge

B. PERFORMANCE REQUIREMENTS:

- 1. Airflow: 1600 CFM (45.3 CMM)
- 2. Motor horsepower: 1 hp fan and 3/4 hp cylinder
- 3. Reversing cylinder
- 4. Control system
 - a. Programming methods: Machine keypad, Infrared (PC or PDA)
 - b. 30-Cycle Capability
 - c. PC software to program machine and/or audit machine performance
 - d. Record last eight machine errors by date and time
 - e. Over Dry Prevention Technology (OPTidry^(TM)) system utilizes two cylinder lifters as sensors (note: some capacities only have one sensor lifter)
 - f. Maintenance-free rotary transfer switch communicates signal between OPTidry^(™) sensor/lifters and control
 - g. Wrinkle free at cycle end allowing 30 seconds of tumble and 1-1/2 minutes of rest until door opens or maximum of one hour
- 5. Lint filter: 1301 sq. inch (8394 sq. cm), self cleaning, depositing lint to large storage area at bottom of tumbler

1.03 DELIVERY, STORAGE AND HANDLING

- A. ACCEPTANCE AT SITE:
 - 1. Inspect machine for damage prior to acceptance. If damage is found, follow freight handler's procedure for claims.
- B. STORAGE AND PROTECTION
 - 1. Machine should be stored in a site protected from weather, direct sunlight and temperature extremes. Do not remove packaging prior to storage.
 - 2. If machine is to be stored for an extended period of time, consult manufacturer for special requirements.

1.04 WARRANTY

- A. Warranty Period: Three years, limited, parts only, commencing on Date of Substantial completion
- 1.05 SYSTEM STARTUP AND COMMISSIONING
 - A. Machine installation should be inspected by local manufacturer's representative prior to startup and operation. The party installing the machine is responsible for setting the schedule for this inspection.

PART 2 PRODUCTS

- 2.01 MANUFACTURERS
 - A. Alliance Laundry Systems LLC UniMac, obtain commercial laundry equipment from a single manufacturer
- 2.02 QUALIFIED MODELS
 - A. UniMac model UT120SRE (no substitutions permitted)

PART 3 EXECUTION

- 3.01 INSTALLATION
 - A. Refer to and comply with manufacturer's installation instructions. Do not deviate without permission from site owner, architect, general contractor and manufacturer's local representative.