# SECTION 11110

### LAUNDRY WASHER-EXTRACTOR, 40 LB. (68 KG) CAPACITY

#### PART 1 GENERAL

- 1.01 SECTION INCLUDES:
  - A. Automatic laundry washer-extractor for processing water-washed linen items

### 1.02 SYSTEM DESCRIPTION

- A. DESIGN REQUIREMENTS:
  - 1. Construction: Stainless steel cylinder, tub and cover panels
  - 2. Input voltage:X: 220-240/60/1 or 3; 2-3 wire plus ground
    - Q: 220-240/60/3; 3 wire plus ground
      - P: 380-415/50/3; 3 wire plus ground N: 440-480/60/3; 3 wire plus ground
  - 3. Dry weight capacity: 40 lb.
  - 4. Wash cylinder volume: 6.34 cu ft. minimum
  - 5. Overall width: 30.63 inches nominal
  - 6. Overall height: 48.7 inches nominal
  - 7. Overall depth: 42.25 inches nominal
  - 8. Number and size of water connections: 2 with 3/4 inch NH male connectors
    9. Number and size of drain outlets: 1 at 3 inch
  - 10. Overflow: Internally plumbed
  - 14. Control evetere: Brogrammable mission
  - 11.
     Control system:
     Programmable microprocessor
  - 12. Cylinder drive: Inverter drive, poly V belt system
  - 13. Drive motor: 2 hp
- B. PERFORMANCE REQUIREMENTS:
  - Number of selectable wash speeds: 2
     Number of selectable extract speeds: 2
     G-force at highest extract speed: 100
  - 4. Chemical supply system
    - a. manually filled 4 compartment dry chemical dispensing system
    - b. automatic flushing and connections for 5 external supply lines and control signals for 4 external supplies

- 5. Control system
  - a. Programmable microprocessor; (manual, PDA or laptop PC)
  - b. 9 programmable cycles
  - c. 3 programmable water levels
  - d. Cycle counter
  - e. Thermal cool down
  - f. Water monitoring: fill value, slow drain and automatic leak detection system
  - g. Diagnostic capabilities
- 6. Drain valve automatically opens in event of power failure
- 1.03 DELIVERY, STORAGE AND HANDLING
  - A. ACCEPTANCE AT SITE:
    - 1. Inspect machine for damage prior to acceptance. If damage is found, follow freight handler's procedure for claims.
  - B. STORAGE AND PROTECTION
    - 1. Machine should be stored in a site protected from weather, direct sunlight and temperature extremes. Do not remove packaging prior to storage.
    - 2. If machine is to be stored for an extended period of time, consult manufacturer for special requirements.
- 1.04 SYSTEM STARTUP AND COMMISSIONING
  - A. Machine installation should be inspected by local manufacturer's representative prior to startup and operation. The party installing the machine is responsible for setting the schedule for this inspection.

#### PART 2 PRODUCTS

- 2.01 MANUFACTURERS
  - A. Alliance Laundry Systems LLC UniMac, obtain commercial laundry equipment from a single manufacturer
- 2.02 QUALIFIED MODELS
  - A. UniMac model **UCN040HNF** (no substitutions permitted)

#### PART 3 EXECUTION


- 3.01 INSTALLATION
  - A. Refer to and comply with manufacturer's installation instructions. Do not deviate without permission from site owner, architect, general contractor and manufacturer's local representative.

# Machine Dimensions and Specifications Model UCN040HNF



Design 2

## **Dimensions and Foundation Requirements**



FRONT

### **Electrical Specifications**

	Voltage	Designat	ion	Non-Electric Heat Machines (Standard)				
Code	Voltage	Cycle	Phase	Wire	Full Load Amps	Breaker (Non Fused)	AWG	mm <sup>2</sup>
Х	220-240	60	1/3	2/3	6	15	14	2.5
Q	220-240	60	3	3	4	15	14	2.5
Р	380-415	50	3	3	3	15	12	4.0
Ν	440-480	60	3	3	3	15	12	4.0

BACK

### Water, Drain and Weight Specifications

Drain: Number (Size)	1 (3 in.)		
Water Connections: Number (Size)	2 (0.75 in.)		
Weight: Machine (With Shipping Packaging)	550 lbs. (590 lbs.)		
Side Clearance:	2 in. (from wall) 0.5 in. (between machines)		

CHM1L